



- 1) You need to check the Transport area C-Blocks in AP0, verify that the chains are in place and locked. Bring AP0 keys.
- 2) Enter the Transport enclosure from the downstream end of AP0.
- 3) Reset Interlock Box #1 at entrance at top of stairwell.
- 4) When you get to the bottom of the stairs you will need to check the upstream section.
- 5) A & B sweep the enclosure to the "Y".
- 6) A waits while B sweep the area to reset Interlock Box #2.
- 7) B then sweeps the area to reset Interlock Box #3.
- 8) B joins A and they Control Access out of the Enclosure